

CLASSIC

Disassembly and repair instructions

Personal locker



Removal/replacement

Spare parts
Door removal / replacement

Page 2
Page 3-8

Disassembly & Recycling

Recycling





Page 9

Save this document for future use.
This document provides information that may be subject to change without prior notice.

CLASSIC

Personal locker

Available spare parts




No.	AJ article	Description	Benämning
1	60672	Right door stopper	Höger dörrstopp
1	60673	Left door stopper	Vänster dörrstopp
2	60675	Rivet	Popnit
3	60670	Right riveting plate	Höger nitbeslag
3	60671	Left riveting plate	Vänster nitbeslag
4	60676	Plastic grommet	Genomföring
5	60674	Hinge	Gångjärn
6	60679	Right Hinge plate	Höger gångjärnsbeslag

CLASSIC

Personal locker

Door removal/replacement

1




CLASSIC

Personal locker

Door removal/replacement

2





CLASSIC

Personal locker

Door removal/replacement

3







CLASSIC

Personal locker

Door reinstall

1







CLASSIC

Personal locker

Door reinstall

2




CLASSIC

Personal locker

Door reinstall


3



CLASSIC

Recycling

Personal locker



PARTS DIAGRAM AND MATERIALS MATERIALSPECIFIKATION

Part no.	Description / Beskrivning	Material
1	Cabinet / Skåp	Metal / Metall
2	Plastic grommet / Genomföring	Plastic / Plast



RECYCLING

To disassemble the furniture for proper recycling, start by removing all screws and fasteners, then separate materials like plastic, metal, and fabric before taking them to the respective recycling facilities.



ÅTERVINNING

För att demontera möbeln för återvinning, börja med att ta bort alla skruvar och fästordningar, sedan separera material som plast, metall och tyg innan du tar dem till respektive återvinningsanläggningar.